

ECO CHAIR

ASSEMBLY INSTRUCTIONS

1. Carefully unpack all contents from packaging, then locate the seat/base and the chair back.

2. Turn the base to the upright position on the floor.

3. Carefully position the back bar over the slot in the rear of the seat. Insert the bar into the slot and set the back to the desired height.



4. Secure the back by tightening the plastic knob.



For use on all Eco Value and EcoMesh chairs.

Corcraft
PRODUCTS



Corrections and
Community Supervision